



**Generating Set** Diesel - Electric start up

# **GE.ECHO 110 K DT AE**











#### Technical data

Standard voltage	V	230	400	
Power	kVA	6,5*	10	
Active power	kW	5,2	8	
Speed	rpm	3000		
Frequency	Hz	5	0	
Current	А	22	14	
Voltage accuracy	V	+/- 5%		
Frequency accuracy	Hz	+/- 4%		

 $^{st}$  Not to be taken simultaneously with the three-phase power.



### **General data**

Start-up	Туре	Electric
Sound pressure level @ 7 mt	dbA	80
Tank	Lt	13
Fuel consumption @ 4/4 load	Lt/H	1,8
Battery capacity (recommended)	Ah	45
Exhaust pipe diameter	Mm	35
Dimensions (LxWxH)	Mm	850 x 520 x 750
Dry weight	Кд	145



#### **Engine**

Brand	-	KOHLER
Model	-	KD330
Cooling	Туре	Air
Cycle	Туре	Diesel 4-stroke
Mechanical power	KWm	12
No cylinders / arrangement	-	2 - L
Brore x stroke	Mm	80 x 65
Displacement	Cm³	654
Speed governor	Туре	Mechanical



### Alternator

Phases	-	3 + N
Degree of protection	-	IP21
Cooling	-	Air forced
Voltage regulator	Туре	Condenser
Waveform distortion	%	<5



# **Environmental conditions**

Temperature	℃	25
Relative humidity	%	30
Maximum altitude	Mt	1000



























EQUIPMENT
Forklift chassis with integrated anti-tip
Raised chassis
Easy start-up
Alternator stabilized, high performance
Handle for short displacements
Start battery
Easy maintenance

## Anti-vibrating mounting pads

CONTROL PANEL
n.1 CEE socket 16 A 2P + T
n.1 CEE socket 16 A 3P + N + T
Thermal circuit breaker
LED Voltmeter
Hourcounter
Magnetothermal

Protection system to



**ON BOARD** 

electrical separation DOCUMENTATION

User and maintenance manual EC Declaration of Conformity

OPTIONALS	
OI HOMALS	

Exhaust flexible pipe kit

Off road trailer kit

Remote control from 20 to 50m. Additional tank 20 lt

Remote control Connector: O.G-CNA-01

Automatic Transfer switch + GS interface: QA.MPE.017B



The QAMPE panel permits the control and the management of the generating sets in case of emergency with the main. It controls the main, the engine and the battery and intervenes in case of necessity. It is also provided with a manual command in case of electronic breakdown that keeps active the protections of the generating set. It get ready for remote control and is equipped with a powerful and precise battery charger.





